





# COOKTOP PARTS

For Models: RY160LXTS0  
(Stainless Steel)

30" Slide-In  
Electric Range




Illus. No.	Part No.	DESCRIPTION
1	W10165716	Literature Parts Use & Care Guide
	W10166918	Wiring Diagram
	W10165721	Installation Instructions
2	74011071	Cooktop, (Black)
3	12001676	Kit, Hardware
4	74007159	Element RF/LR(2)8"
5	74007158	Element LF/RR(2)6"
6	74005759	Tube, Vent Upper
7	74003357	Screw (4)
8	74006046	Bottom, Burner Box
9	74001212	Bowl, Drip(Chr 6")
10	74001213	Bowl, Drip(Chr 8")
11	74010894	Bracket, Burner Box

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: RY160LXTS0  
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	7730P011-60	Lens
2	W10168895	Panel, Control
3	7101P309-60	Screw, Switch (10)
4		Switch, Infinte
	7403P239-60	8" (RF/LR)(2)
	7403P238-60	6" (LF/RR) (2)
5	W10169865	Control W/Overlay

Illus. No.	Part No.	DESCRIPTION
6		End Cap
	74010835	Left Black
	74010834	Right Black
7	74009527	Screw, End Cap
8	74008718	Switch, Rocker
9	74004288	Screw, Control


Illus. No.	Part No.	DESCRIPTION
10	74004785	Support, Control Panel
11	7101p338-60	Screw, Support (4)
12	74001337	Shield, Heat
13	74004153	Light, Indicator
14	74003612	Knob (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RY160LXTS0

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CHASSIS PARTS

For Models: RY160LXTS0

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	74010821	Panel, Shield Left	19	74010817	Holder, Vent Tube	39	74007129	Support
	74010822	Right	20	74008597	Smoke Eliminator	40	74003565	Runner, Drawer (2)
2	74010897	Latch Assembly	21	W10165724	Plate, Smoke Elm.	41	74004078	Roller, Drawer (2)
3	74001075	Lever, Lock	22	74010885	Light Assembly	42	74005231	Shaft, Roller (2)
4	74011465	Main Back	23	74004180	Bracket,Pwr Supply	43	74005230	Nut, Lock (2)
5	74006096	Cover, Main Wire	24	7407P103-60	Bulb, Oven	44	74006522	Retainer, Bottom
6	74010815	Extension, Back	25	74010831	Trim, Side (Black)	45	74005564	Bracket, Anti-Tip
7	Y700502	Screw	26	74003976	Screw,Shoulder (4)	46	7101P124-60	Screw, w/Washer
8	74006364	Insulator, Cord	27	74010883	Element, Bake	47	74010812	Support, Ov Bottom
9	74005264	Panel, Access	28	74010884	Support, Oven Rear	48	74003976	Screw,Shoulder (2)
11	74010823	Fan, Cooling	29	71001394	Screw	49	74010807	Cover, Front
12	74008298	Block, Bare Wire	30	74011142	Hinge (2)			
13	74004223	Connector, Cable	31	7101P112-60	Screw, Hinge (4)			
14	74003040	Element, Broil	32	74010818	Switch, Hi-Limit			
15	74004943	Sensor, Oven	33	74003975	Screw, Lever (2)			
16	W10165822	Tube, Vent Lower	34	74010820	Extention, Shield			
17	74010886	Tube, Vent Upper	35	74003386	Support, Element			
18	71001394	Screw (4)	36	74010805	Leg, Leveling			
			37	74010899	Pedestal, Bottom			
			38	74010882	Pedestal, Front			


## INSULATION

74010987	Insulation, Wrap
W10165725	Insulation, Back
74011207	Insulation, Oven Bottom

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DOOR PARTS

For Models: RY160LXTS0  
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10168887	Panel, Door (SS)
2	74006635	Screw, Handle (2)
3	74011457	Baffel, Retainer
4	74001530	Screw 8AB 1/2
5	74003645	Glass, Inner (2)
6	74005546	Spacer, Rubber
7	74001574	Nut, Snap (4)
8	74011456	Lining, Door


Illus. No.	Part No.	DESCRIPTION
9	74011458	Bracket, Glass (2)
10	74003647	Insulation, Door
11	Y700502	Screw
12	74011048	Insulation, Foil
13	74010043	Insulation, Door
14	74011049	Shield, Door
15	74004224	Tape, White
16	74010231	Glass, Coated

Illus. No.	Part No.	DESCRIPTION
17	74003649	Glass, Inner Clear
18	74011050	Retainer, Glass
19	74009029	Gasket, Window
20	W10168886	Tape, Protective
21	7112P034-60	Clip, Glass (2)
22	7201P046-60	Seal, Door
23	74008318	Handle, Door
24	8303811	Nameplate, Logo

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DRAWER AND RACK PARTS

For Models: RY160LXTS0  
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	74001757	Rack, Oven (2)
2	74008333	Drawer, Storage
3	74004310	Screw, Panel
4	74010896	Bracket, Drawer

Illus. No.	Part No.	DESCRIPTION
5	7760P229-60	Panel, Dwr (SS)
6	74001530	Screw, Panel
7	74005230	Nut, Lock
8	2404F030-51	Lining, Drawer
9	74005546	Spacer, Rubber

Illus. No.	Part No.	DESCRIPTION
10	74004078	Roller, Drawer (2)
11	74005231	Shaft, Roller (2)
12	7103P082-60	Nut
13	74009841	Handle, Drawer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: RY160LXTS0

(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		

## SPLICING WIRES--25FT.

### LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

## INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

## PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

## ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3191048	Cleaner, Glass

## WIRING HARNESS PARTS

74010890	Harness, Sensor
74010891	Coil, Harness (Rt)
74010893	Coil,Harness (Lt)
W10169071	Harness, Main
74011206	Cable, Assy.(Flex)
74006811	Clip, Wire
7101P027-60	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST